

#### Door care and handling:

- Always stack the widest doors at the bottom
- Ensure that the bearers are wider than the door
- Use at least three load bearers to allow equal weight distribution
- Do not allow direct sunlight on the doors, as this may cause fading
- Doors need to be kept flat and not stood up - this will prevent bowing
- When handling timber products, normal hygiene standards should be used before food and drink is consumed
- Doors are specifically routed/serviced to suit our frame after the finish of the door has been applied, therefore the rebated back section and rebated front will need to be primed
- The door must not be stored or fitted in a building with wet trades. For example, plastering should have been finished and given time to completely dry. Doors and frames must be stored in dry conditions and free from excessive moisture levels
- Self-adhesive tape (whether low-tac or otherwise), used while adding site protection to door faces and edges during installation; must not come into direct contact with the actual face or edge of the door. This has the potential to cause damage and so the doors would not be covered under our normal guarantee should this have occurred
- Products manufactured from timber-related materials. along with the packaging, are combustible, therefore the product should be stored away from radiant heat or fire. In case of fire, use water to extinguish. When using timber products splinters may occur. Care should always be taken and where appropriate protective gloves should be worn